

INSTRUCTIONS
FOR
INSTALLING AeroDynic® DOME ASSEMBLY

1. Remove two screws located at identification plate. Slide dome assembly out.
2. To install dome assembly, line-up the curved hook ends of the dome assembly with the slots in the extrusion. **IMPORTANT:** You may have to slightly bow the dome assembly out to allow it to line-up with the extrusion slots.
3. Slide-on dome assembly and secure with two screws removed in step 1.

